


Major 4a

Software Option
Motorola MOTOTRBO



Major 5a

Software Option
Motorola MOTOTRBO



FunkTronic

Competence in electronics

Contents	Page
Order Information	2
General Information	3
Important Settings at the Motorola MOTOTRBO	4
Control Elements Major 5a	5
Control Elements Major 4a	5
Display Elements Major 4a / 5a	6
Sockets Pinout Major 4a/5a	7
Rearview Major 4a/5a	7
RS232 Interface	8
RS232 Cable for Flashing/Printing/Monitoring	8
Configuration of the RS232 Interface	8
Example Configurations	9
Standard Keypad Assignment Major 5a	10
Standard Keypad Assignment Major 4a	10
Differences Major 4a - Major 5a	11
Keypad Assignment Major 5a in Programming Mode	11
Keypad Assignment Major 4a in Programming Mode	11
Menu Structure	12
Programming Short Call	15
Configuration of the Software	15
Changing the Assignment of Button Functions	16
Customizing the Call Input	17
Reset to Factory Defaults	17
Transmit/Receive SDS (ab V3.03)	18
Analog Channels	18
ACK Request	18
Default Group Call (since V3.06)	18
Registerbelegung Major 4a, Major 5a	19
Programmable Functions	22
Technical Data	24
General Safety Information	25
Returning of Old Equipment	25

Order Information

Order No.	Description
681000.MOT	Major 4a incl. Option MOTOTRBO
714000.MOT	Major 5a incl. Option Motorola MOTOTRBO
903050	Distribution Frame (Überleitverteiler) DMR, 2-fold
903051	Distribution Frame (Überleitverteiler) DMR, 3-fold
	Distribution Frame (Überleitverteiler) DMR, available on demand up to 9-fold
	Attention: Power Supply Unit, Interface and cables are not included
900012	Power Supply Unit 230V/12V for Major 4a + Major 5a
900020	Interface-Audio-USB-RS232-RS485
900920	Connection Cable Motorola DM3400 <-> 900020, length ca. 1m

General Information

In order to allow the connection to a digital radio of the Motorola MOTOTRBO series, **Major 4a** and **Major 5a** can be equipped with the **software option Motorola MOTOTRBO**.

Thus, the Major 4a/4a with MOTOTRBO option can be used as a (remote) control panel for Motorola MOTOTRBO radios. At the moment, the following functions are supported:

- The MOTOTRBO should operate in digital mode. For channels defined as analogous channels, only some simple functions are available.
- call IDs 00001-99999
- initiate and receive/display selective call
- initiate and receive/display group call
- channel selection
- receive/display emergency call (only for DM36xx and DM46xx)
- transmit and receive call alert
- memory for call-IDs
- transmit and receive SDS with up to 24 characters

General features of Major 4a/5a:

- alphanumeric LC display with background lighting
- gooseneck microphone with high dynamic range
- plaintext menu structure for simple programming via the keypad
- all buttons are freely programmable
- two functions can be assigned to each button
- A Motorola MOTOTRBO radio can be directly connected (via 1 Audio-USB Interface-Box)
- A Motorola MOTOTRBO radio can be remotely connected (via 2 Audio-USB Interface-Box)
- Two sockets for control via headset, one of those for connection of a PTT foot switch
- 7 digital In/Outs for channel switching or other purposes
- operates via an external 12V-DC power supply

Attention: Major 4a/5a are connected via the “Non IP“-mode of the MOTOTRBO radio. This mode is not working for the firmware version R01.06.20 with the following radios:

- DM3400 - Numeric Display Mobile Radio
- DM3401 - Numeric Display Mobile Radio with GPS
- DM3600 - Enhanced Display Mobile Radio
- DM3601 - Enhanced Display Mobile Radio with GPS

Motorola recommends the use of the preceding firmware version (R01.06) from spring 2010 or alternatively a newer version, as soon as it is available.

We recommend to use a radio of type DM36xx, as the DM34xx does not support certain functions. These functions are at the moment (firmware version R01.08.XX) as follows:

- display the channel name
- receive and display incoming emergency calls
- cancel an incoming call alert

Important Settings at the Motorola MOTOTRBO

For the operation of Major 4a/5a with the Motorola MOTOTRBO two settings need to be made using the “MOTOTRBO Customer Programming Software“

- Language: German, English,....

In the Content Tree via “General (Properties)“

- cable type: Data/Accessory at the Rear

In the Content Tree via “Accessories“

To be able to make these changes, the view must be set to “expert mode“. This is achieved via the item “view“. Here, you have to check the box named “expert“.

The following image shows the settings for “cable type“.

Inhaltsverzeichnis

The screenshot displays the 'Zubehör' (Accessories) configuration page in the Motorola MOTOTRBO software. On the left, a sidebar titled 'Inhaltsverzeichnis' (Table of Contents) lists various settings categories, with 'Zubehör' highlighted. The main window shows the 'Zubehör' settings, including options for 'Lautstärkeregler' (checked), 'Zündungssteuerung' (Ein/Aus oder Zündung), 'Handhörer' (unchecked), microphone gain settings for analog and digital front and rear, 'Audiotyp Empfang' (Rauschsperr gefiltert ein), 'Datenkanal' (Gewählt), 'Verzögerungsdauer' (100 ms), and 'Kabeltyp' (Daten/Zubehör hinten).

Control Elements Major 4a



Control Elements Major 5a



LC Display

All alphanumeric readouts are presented by a LC display with background lighting.

Here, in the left part of the top line 14 digits are reserved for the channel name. In the right part, the input of the call ID is displayed. If permanent channel display is not activated, the whole line is used for the call ID input.

The bottom line is used to display information obtained from the radio, e.g. caller alias or other information.

Status LEDs

Carrier Display (Squelch) ▼

The carrier display LED ▼ can be controlled by voice (2-wire connection) or via squelch input (using the radio set). If the light is on, the radio circuit is occupied, that is, a carrier signal (carrier is keyed) is present.


PTT Display (Push-to-Talk) ▲

The PTT display LED ▲ is on, if the transmitter is keyed. Keying of the transmitter is achieved by pressing the PTT button during telephony or by sending a call.

Loudspeaker Display (Incoming Call) ■

The loudspeaker display LED ■ is on, if the loudspeaker or the earphone capsule in the handpiece are switched on.

Rearview Major 4a/5a




PWR operating voltage 12V, max. 1,5 A
inside: positive terminal, outside: GND

Sockets Pinout Major 4a/5a

All of the schemes show the sockets as viewed from the rear of the Major.

Pinout S/E Radio Circuit (ST1)

AF input B
AF input A
Squelch input
GND
output +12 V, max. 200 mA
PTT active, low
AF output A
AF output B




All AF in/outputs are equipped with transformers and, hence, potential-free. PIN 5 is for supply (+12V) of external devices (LIM-AC, FT634C).

Attention: Do not use PIN 5 to supply a radio set. 200 mA output current is not sufficient.

Pinout I/O Digital In/Outputs (ST3)

IN/OUT 0
IN/OUT 1
IN/OUT 2
IN/OUT 3
IN/OUT 4
IN/OUT 5
IN/OUT 6
GND




The digital connections can be configured as inputs or outputs, respectively. Usually, these are used as outputs for remote channel select.

There are two sockets for connecting a headset. One is for connecting the headset, the other for the use of an external PTT button (e.g. foot switch)


Pinout HS Headset (ST2A)

GND
AF input (mic. +)
AF earphone
GND earphone
GND AF input (mic. -)
PTT, active GND




Pinout PTT Headset (ST2)

GND
GND AF input (mic. -)
NF earphone
GND earphone
AF input (mic. +)
PTT, active GND




Pinout RS232 (ST4)

NC
NC
TxD
RxD
GND
NC



RS232 Interface




ST4 RS232 Interface

RS232 Cable for Flashing/Printing/Monitoring

RS232 25pin connector on computer

RS232 socket on Major




Configuration of the RS232 Interface

9600 Baud, 8 data bits, no parity, 1 stop bit, no protocol

RS232 9pin connector on computer

RS232 socket on Major




Example Configurations


Direct Connection to the Radio



Remote Control of the Radio




Several Control Panels, remotely Connected to the Radio




Standard Keypad Assignment Major 4a

- ... : number input (call, channel, status...)
- short : transfer ID-code to call input
- long : delete whole call input
- short : scroll through ID-code memory
- long : delete ID-code from memory
- : channel input
- : PTT gooseneck mic / status
- : short: toggle selective call / group call
long: send call alert to call ID
- : volume control







Standard Keypad Assignment Major 5a


Comparable to Major 4a, but without the additional buttons S1...S4 and F1...F4.



Keypad Assignment Major 4a in Programming Mode

Button  reduces by 1, button  increases by 1.

The values A - F are assigned to the buttons S1...S4,  and .



Keypad Assignment Major 5a in Programming Mode

Long pressing of buttons 1 to 6 results in the additional values A-F..

The call button reduces by 1, and the red PTT button increases by 1.



Differences Major 4a - Major 5a













The Major 4a is different from the Major 5a in the following points:


1. different keypads
2. Major 4a has a handset, Major 5a has none
3. differences in the software, mainly resulting from point 1+2

Menu Structure

Simultaneous pressing of the buttons  and  opens the menu.


Due to the different keypad designs, for the same operations different keys are used in Major 4a and Major 5a. In the following, the handling of Major 4a is described. For the respective keys that have to be used in Major 5a please consider the table below.

Function	Major 4a	Major 5a
next menu		
select menu item		
escape discarding changes		
save changes and escape		
increase value by 1		
reduce value by 1		



Menu Structure

continued



0	=	200 Hz
1	=	300 Hz
2	=	400 Hz
3	=	600 Hz
4	=	800 Hz
5	=	1000 Hz
6	=	1600 Hz
7	=	2400 Hz
8	=	3400 Hz
9	=	4000 Hz
S1	=	2900 Hz
S2	=	3000 Hz
S3	=	3100 Hz
S4	=	3300 Hz
*	=	1200 Hz
#	=	1800 Hz

- = reduce contrast by 1
- = increase contrast by 1
- = escape menu
discarding changes
- = save changes,
escape menu


- = one digit to the left
- = one digit to the right
- = escape menu
discarding changes
- = save changes,
escape menu

The values can be changed directly using the buttons 0 to 9.

= escape menu

Menu Structure

continued



- displayed for 3 seconds

= one digit to the left

= one digit to the right

The onboard clock is factory calibrated. Before changing the values please note down the current values. Higher values accelerate the clock, while lower values slows it down. Changes made in digital have more effect than changes made in analog. Fine adjustment must be done in analog, step by step.

= escape menu
discarding changes


= save changes,
escape menu

Configuration of the Software

Programming Short Call

In the following a programming example of the Major's registers is shown. The procedure is always the same. Depending on the desired effects, however, the programming of several registers can be necessary.

This example illustrates the programming of short call 1 in register 001 with the tone sequence 12345.



The line „Code“ shows the present programming of the register. The displayed value can be overwritten with the new value.

With button **F3** the menu can be quit any time discarding the changes.

With button **F4** the displayed value is programmed.

As every button of the Major 4a/5a is freely programmable, the registers 174 and 175 for the Z-button have to be programmed with the right values. As this already is the case in the factory defaults, this step is not necessary.


Hence, register 174 (function Z-button, short press) usually is programmed with 22F01 and register 175 (function Z-button, long press) with 00000. The first 0 in register 175 defines that no

additional function of the button is exercised upon long pressing.

The digits of register 174 have the following functions:

1. digit = 2 --> function 2 - transmit call
2. digit = 2 --> enter short call
3. digit = F --> awaiting input

Here are the steps that are necessary to check if the programming in register 174 is suitable for short call selection.



Changing the Assignment of Button Functions


All buttons of the Major 4a/5a are freely programmable. The numeric keys, the * and # keys as well as the function buttons for volume (only Major 5a), loudspeaker, short call, call and PTT are programmed ex factory for the respective tasks.

Every button can be assigned two different functions. One is achieved by pressing the button shortly and the other by pressing it for a longer time.


If the button is pressed for less than a second, the function programmed for „short press“ is executed. For longer pressing the function programmed for „long press“ is executed. If no function is programmed for long press, the „short press“ function is executed immediately.

Programming of the button's functions is done in registers 130-179. For every button 2 registers are reserved, the first one for short press, the second one for long press (see Table of Registers, registers 130-179). Every register contains 8 digits. For details on all function see section **Programmable Functions**.

The function of the LEDs in buttons F1 to F4 is defined in registers 180-183.

Here's an example for programming button .


Programming „short press“:




- 1. digit 7 = function --> number input
- 2. digit 1 = number input --> new input
- 3. digit 1 = value 1 (0...F possible)


4.-8. digit 0 = not regarded

For saving, the following actions are necessary:



Ex factory, no function is programmed for long press of button . As an example, we are programming the button to set the volume to "1". wird hier die Lautstärke Stufe 1 programmiert.

Programming „long press“:




Customizing the Call Input

In **reg. 010** you can define the variable digits for **selective call input**.

If **reg. 010** is **FFFFF000**, all 5 digits must be entered via the keypad. If digits 1-3 should be fixed and only digits 4+5 are to be entered, **015FF000** must be programmed.

The **group call input** is configured accordingly in reg. 012.


Example: Input of all 5 digits via the keypad



Reset to Factory Defaults

Using the following steps, Major 4a can be reset to factory defaults.

Attention! All parameters are reset to the default values without further confirmation.



When entering register 223 the potentiometers are also reset to factory defaults.

Transmit SDS

The Major can send 10 different SDS messages with lengths of up to 24 characters, each. These messages are transmitted to the currently displayed group call number or selective call number. To achieve this, a suitable button must be programmed with the respective function (e.g. **253F0000**, see section **Programmable Functions**).

In order to program your customized SDS texts, the Major 4a/5a must be connected to a PC using a RS232 connection cable. If your PC does not have a real COM port (9-pin SUB-D socket) a USB-to-COM adapter can be used.

In order to read-out the texts you have to enter the following 6 characters into your terminal program:

Ctrl-B + "SDS?" + Ctrl-C

To program the texts you have to enter the following 30 characters:

Strg-B + "SDSxyyy...y" + Strg-C,
where x is the SDS number (0-9), the y's are the characters of the text (24 in total).

Receive SDS

Received SDS messages are stored in the ID-code memory. Here, a single SDS consists of max. 14 characters for the originator's name and max. 2x14 characters text. The display alternately switches through the name and the 2 text lines. As in the Kenwood radios, no alias is available, the originator's call ID is displayed. For configuration of SDS display and ID-code see **reg. 087**.

Necessary Settings - Audio/USB Interface

For support of the new SDS functions an Audio-USB interface with software V1.06 or newer is needed. In the interface's register 010, the same CAI values need to be programmed, as are programmed in the radio (CPS: network > radio network > CAI network and CAI group network).

reg.010/1-3: CAI network (Def.:012)
reg.010/4-6: CAI group network (Def.:225)
reg.010/7: transmit pos/neg. acknowledge-
ment tone

For software version 3.05 and newer up to 4 channels can be defined as analog channels. However, the functions are limited to the most essential ones (e.g. 5-tone encoder/decoder and PTT). In contrast to the digital channels, a call is transmitted using the call button, like in the standard software of Major 4a/5a.

The following registers are used for configuration:

Reg. 013: 5-tone encoder

Reg. 067: channel numbers of the analog channels

Reg.184/185: function of the call button in analog mode

ACK Request

For SW version 3.06 an newer the acknowledge (ACK) request is supported for the more recent NEXEDGE radios (SW version 4.40.00 and newer), too. To send ACK requests with the PTT, **digit 8 in reg.050** must be programmed to **1**.

Default Group Call (since V3.06)

It is now possible to define a standard group call, to which the display is reset after a certain idle time. Thus, your standard group does not have to be entered, but is usually available just by pressing the red PTT button (see **Reg. 060**).

Register Programming Major 4a, Major 5a

reg.	function	reg.	function
000	short call 0-9	8 th digit:	0 = decoder off 1 = decoder on
-009	1 st digit: 0 = group call, 1 = selective call 2 nd -6 th digit: variable digits, that must be entered	030	configuration 1 for decoder 1
010	selective call register 1 st -5 th digit: digits for selective call variable digits are coded as F 6 th digit: display the programmed group call if digits 1-5 are not programmed y/n (1/0)	031	configuration 1 für decoder 2
011	general configuration 1 st digit: language 0 = German 1 = English 2 = French 3 = Dutch 4 = Italian 5 = Czech 4 th digit: RS232 monitor is on/off (1/0) at power-on 5 th digit: pressing *+# (or F1+F4) is necessary for n*1s to enter programming mode 0 = immediately F = disabled	032	configuration 1 für decoder 3
012	group call register 1 st -5 th digit: digits for group call variable digits are coded as F 6 th digit: display the programmed group call if digits 1-5 are not programmed y/n (1/0)	033	configuration 1 für decoder 4
013	5-tone encoder (analog channels) 1 st -5 th digit: e-tone sequence, variable digits are coded as F 6 th -8 th digit: must be coded as 0	034	configuration 1 für decoder 5
020	decoder 1	035	configuration 1 für decoder 6
021	decoder 2	036	configuration 1 für decoder 7
022	decoder 3	037	configuration 1 für decoder 8
023	decoder 4	038	configuration 1 für decoder 9
024	decoder 5	039	configuration 1 für decoder 10
025	decoder 6	030-039:	1 st digit: alarm tone type 2 nd digit: alarm tone duration n*200ms 3 rd digit: alarm tone volume (0-9, A..F=Offset +0...5) 4 th digit: call volume duration n*200ms 5 th digit: call volume
026	decoder 7	040	configuration 2 für decoder 1
027	decoder 8	041	configuration 2 für decoder 2
028	decoder 9	042	configuration 2 für decoder 3
029	decoder 10	043	configuration 2 für decoder 4
020-029:	1 st -7 th digit: decoder, program unused digits with an F	044	configuration 2 für decoder 5
		045	configuration 2 für decoder 6
		046	configuration 2 für decoder 7
		047	configuration 2 für decoder 8
		048	configuration 2 für decoder 9
		049	configuration 2 für decoder 10
		040-049:	1 st digit: ID-mode of call 0 = 5-tone sequence 2 nd digit: switching output: number: 0 (none), 1-7 3 rd digit: switching output: 0(off) F(on) for a variable time: 1-D (0-13)s 4 th digit: acknowledgement: 0 = no acknowledgement 1 = acknowledgement 2 = single tone 3 = own ID-code 4 = received ID-code 5 th digit: Loudspeaker / LED: 0 = no action 1 = LS on 2 = LED fashes 3 = LS on + LED flashes

reg.	function	reg.	function
050	loudspeaker (LS) configuration 1 st -3 rd digit: LS timer: nnn * 1s (000=no timer, FFF=open mode) 4 th digit: LS on taking earphone (only M4a) 0 = off 1 = on 2 = unchanged 6 th digit: n*200ms time for call-back after termination of incoming call alert 7 th digit: termination of incoming call alert is permitted? 0=auto (DM36xx - yes, DM34xx - no) 1 = yes, 2 = no	067	analog channels digits 1+2, 3+4, 5+6, 7+8: numbers of the analog channels e.g.: 01FFFFFF = channel 01 is analog
051	general configuration 1 st -3 rd digit: transmission time limit nnn * 1s. 4 th digit: 0 = 4-wire simplex 1 = 4-wire duplex 2 = 2-wire simplex 3 = 2-wire duplex 5 th digit: 0 = LS is off after call tone sequence is not heard 1 = LS is on after call tone sequence is not heard 2 = LS is off after call tone sequence is heard 3 = LS is on after call tone sequence is heard	083	configuration for radio mute 1 st digit: output for radio mute 0=off 1-7,8=TX 2 nd digit: logics of radio mute function 1=RX 2=TX 3=RX+TX 1-3=active low if criteria are met 5=RX 6=TX 7=RX+TX 5-7=active low if criteria are not met 3 rd digit: after-run time (n*1s)
052	display lighting 1 st -3 rd digit: lighting is active for nnn *1s 000 = lighting disabled 001 = lighting is always on	087	ID-code display 1 st +2 nd digit: display time ID-code/SDS nn*100ms 3 rd +4 th digit: display time of one SDS part nn*100ms 5 th digit: no flashing of the LS LED upon incoming: 1: ID-code 2: SDS 3: ID-code or SDS
055	general configuration 3 rd digit: key beep (on/off = 1/0)	095	configuration I/O 1-5 (digits 1-5)
060	timer for reset to default group 1 st -3 rd digit: time until reset nnn*1s 000 = deactivated 6 th -8 th digit: default group FFFFF: reset deletes group	096	configuration I/O 6-7,TX (digits 1-3)
066	configuration for channel select 1 st digit: 0 = ne channel select 1 - 3 = channels of 1-3 digits 5 - 7 = channels of 1-3 digits which are displayed permanently 2 nd digit: 0 = numeric channel display 1 = display channel name (not available for DM34xx and DM44xx)	095-096:	0: none 1: output 2: input, active low 4: input, active high 8: output, outside switching 9: output, inverted
		097	service password (master password)
		099	customer password
		100	volume 1 st digit: save last volume y/n (1/0) 2 nd digit: volume at power-on
		103	short call A
		104	short call B
		105	short call C
		106	short call D
		107	short call E

reg. function

In registers 108 to 129 the functions of the inputs are programmed. Every input has two functions: one upon activation (passive => active) and one upon deactivation (active => passive).

108	function PTT2 passive > active
109	function PTT2 active > passive
110	function IN1 passive > active
111	function IN1 active > passive
112	function IN2 passive > active
113	function IN2 active > passive
114	function IN3 passive > active
115	function IN3 active > passive
116	function IN4 passive > active
117	function IN4 active > passive
118	function IN5 passive > active
119	function IN5 active > passive
120	function IN6 passive > active
121	function IN6 active > passive
122	function IN7 passive > active
123	function IN7 active > passive
124	function TX passive > active
125	function TX active > passive
126	function RX (SQL) passive > active
127	function RX (SQL) active > passive
128	function DC passive > active
129	function DC active > passive

In registers 130 to 179 the functions of the buttons are programmed. Every button has two functions, too: one for short pressing of the button and one for long pressing.

130	function 0 -button short
131	function 0 -button long
132	function 1 -button short
133	function 1 -button long
134	function 2 -button short
135	function 2 -button long
136	function 3 -button short
137	function 3 -button long
138	function 4 -button short
139	function 4 -button long
140	function 5 -button short
141	function 5 -button long
142	function 6 -button short
143	function 6 -button long
144	function 7 -button short
145	function 7 -button long
146	function 8 -button short
147	function 8 -button long
148	function 9 -button short
149	function 9 -button long
150	function S1-button short

reg. function

151	function S1-button long
152	function S2-button short
153	function S2-button long
154	function S3-button short
155	function S3-button long
156	function S4-button short
157	function S4-button long
158	function * -button short
159	function * -button long
160	function # -button short
161	function # -button long
162	function F1-button short
163	function F1-button long
164	function F2-button short
165	function F2-button long
166	function F3-button short
167	function F3-button long
168	function F4-button short
169	function F4-button long
170	function PTT-button short
171	function PTT-button long
172	function RUF-button short
173	function RUF-button long
174	function Z-button short
175	function Z-button long
176	function LS-button short
177	function LS-button long
178	function VOL-button short (only Major 5a)
179	function VOL-button long (only Major 5a)
184	CALL-button in analog mode short
185	CALL-button in analog mode long

In registers 180 to 183 the meaning of the LEDs in the F-buttons is programmed.

180	function LED in F1
181	function LED in F2
182	function LED in F3
183	function LED in F4
180-183: 1 st digit: function	
0: no function	
1: display switching output status	
2: display channel	
3: display telephone mode	
4: display decoder status	
if 1 st digit = 1: display status of switching output	
2 nd digit: 1-7: number of the switching output (1-7)	
3 rd digit:	
0: display, if active low (normal)	
1: display, if active high (inverted)	

if 1st digit = 2: display channel
 2nd+3rd digit: 00-99 (channel 00-99)

if 1st digit = 5: display monitor status
 2. Stelle: 0 = LED on if monitor is on
 1 = LED on if monitor is off

189 headset configuration
 1st-3rd digit: threshold voltage (analog-digital converter for headset detection
 nnn (000-999) * 5mV,
 headset is present if voltage is lower

222 restore factory defaults

223 restore factory defaults including
 potentiometer settings

Attention: factory defaults are restored without
 further confirmation directly after input of the
 register number

Programmable Functions

Programmable functions for buttons and inputs:
 The first digit of the respective register contains
 one of the following functions. The additional
 digits define the function in detail.

1st digit: function
 0: no function
 2: transmit call
 3: PTT
 4: volume
 5: channel selection / switching output
 6: ID-code memory
 7: calling number/tone input
 9: ext. inputs

Function 2 (transmit call):

1st digit: 2: transmit call
 2nd digit: 2: transmit short call
 3rd digit: 0-9: transmit short call n
 F: manual input of short call number
 1st digit: 2: call
 2nd digit: 5: switch call mode
 3rd digit: 0: activate group call
 1: activate selective call
 2: status input on/off
 3: activate SDS
 E: toggle group call / selective call

1st digit: 2: call
 2nd digit: 5: switch call mode
 3rd digit: 3: activate SDS
 4th digit: 0-9: SDS 0-9
 8th digit: 0: send SDS immediately
 1: send SDS when PTT is pressed

1st digit: 2: call
 2nd digit: 7: send SDS to group
 3rd digit: 0-9: SDS 0-9
 4th-8th digit: 00000-99999: group number, to
 which the SDS is sent

Function 3 (PTT):

1st digit: 3: PTT
 2nd digit: 0-3: button starts PTT
 (ends when button is released)
 4-7: input starts PTT
 (ends with function PTT off)
 0,4: gooseneck mic.
 1,5: headset mic.
 2,6: handset mic.
 3,7: gooseneck- or headset mic.
 8: switching of GN / HS mic.
 F: PTT off
 (if started with input)

1st digit: 3: PTT
 2nd digit: 8: switching of GN / HS mic.
 3rd digit: 0: GN microphone is on
 1: HS microphone is on
 2: automatic HS detection
 (Standard after power-on)
 E: toggle GN/HS
 F: input
 4th digit: 0: no text display
 1: n*100ms text display

Function 4 (volume):

1st digit: 4: volume
 2nd digit: 0: toggle loudspeaker (on/off)
 1: volume
 3: toggle monitor function
 1st digit: 4: volume
 2nd digit: 1: volume
 3rd digit: 0-9: volume
 A: increase by 1 step
 B: decrease by 1 step
 F: input
 4th digit: 0-9: minimum volume 0-9
 5th digit: 0-9: maximum volume 0-9

Function 5 (channel selection / switching outputs):

- 1stdigit: 5: channel selection
2nd-4thdigit: 000-999: channel nnn
FFF: input
- 1stdigit: 5: switching outputs
2nddigit: E: set status of switching output
3rddigit: 1-7: number of the switching output (1-7)
F: manual input of the number
4thdigit: 0: switching output off (passive, high)
1: switching output on (active, low)
3: switching output on for defined time
E: toggle switching output (on/off)
F: manual input of the status
6th-8thdigit: 001-255: n*100ms (if 4thdigit = 3)

Function 6 (ID-code / SDS memory):

- 2nddigit: 0: delete ID-code
1: display next ID-code
2: display most recent ID-code
5: copy ID-code to call input
(for call-back)

Function 7 (input calling number/tone):

- 1stdigit: 7: input of calling tone
2nddigit: 0: delete input
1: new input
2: input of complete call

- 1stdigit: 7: input of calling tone
2nddigit: 0: delete input
3rddigit: 0: delete call completely
1: delete last input
2: call +1 (see 4thdigit)
3: call -1 (see 4thdigit)

- 1stdigit: 7: input of calling tone
2nddigit: 1: new input
3rddigit: 0-E: calling tone 0-E
F: break

- 1stdigit: 7: input of calling tone
2nddigit: 2: input of complete call
3rddigit: 1-5: number of digits
4th-8thdigit: 1-5 digits

Function 9 (ext. inputs):

- 1stdigit: 9: external inputs
2nddigit: 1: external muting
3rddigit: 0: muting off
1: muting on
4thdigit: 0: TX-LED is off during silence
1: TX-LED flashes during silence

Function C (simulate MOTOTRBO button):

This function is needed to delete an incoming emergency call. Here, one has to define the button for which "emergency call off" is programmed at the DM36xx or DM46xx.

- 2nddigit:
- | | |
|--------------|-----------|
| 1: button P1 | at DM36xx |
| 2: button P2 | at DM36xx |
| 3: button P3 | at DM36xx |
| 4: button P4 | at DM36xx |
| 9: button | at DM46xx |

Technical Data

Operating Voltage	12 V
Current Consumption	max. 800 mA
Weight	1,5 kg
Dimensions WxDxH (without gooseneck)	245 x 220 x 95 mm
input impedance 2-wire/4-wire	600 Ohm
input level 4-wire	50 mV (-24 dBm) bis 775 mV (0 dBm)
input level 2-wire	70 mV (-21 dBm) bis 1050 mV (+2,5 dBm)
output impedance 2-wire/4-wire	600 Ohm
output level at 600 Ohm	
AF without additional pilot-tone	30 mV (-28 dBm) to 550 mV (-3 dBm)
AF with additional pilot-tone	30 mV (-28 dBm) to 450 mV (-5 dBm)
Set ex factory to	450 mV

General Safety Information

Please read the operating instructions carefully before installation and setup.

The relevant regulations must be complied to when working with 230V line voltage, two-wire-lines, four-wire-lines and ISDN-lines. It is also very important to comply to the regulations and safety instructions of working with radio installations.

Please comply to the following safety rules:

- All components may only be mounted and maintained when power is off.
- The modules may only be activated if they are built in a housing and are scoop-proof.
- Devices which are operated with external voltage - especially mains voltage - may only be opened when they have been disconnected from the voltage source or mains.
- All connecting cables of the electronic devices must be checked for damage regularly and must be exchanged if damaged.
- Absolutely comply to the regular inspections required by law according to VDE 0701 and 0702 for line-operated devices.
- Tools must not be used near or directly at concealed or visible power lines and conductor paths and also not at and in devices using external voltage – especially mains voltage - as long as the power supply voltage has not been turned off and all capacitors have been discharged. Electrolytic capacitors can be still charged for a long time after turning off.
- When using components, modules, devices or circuits and equipment the threshold values of voltage, current and power consumption specified in the technical data must absolutely be complied to. Exceeding these threshold values (even if only briefly) can lead to significant damage.
- The devices, components or circuits described in this manual are only adapted for the specified usage. If you are not sure about the purpose of the product, please ask your specialized dealer.
- The installation and setup have to be carried out by professional personnel.

Returning of Old Equipment

According to German law concerning electronic devices old devices cannot be disposed off as regular waste. Our devices are classified for commercial use only. According to § 11 of our general terms of payment and delivery, as of November 2005, the purchasers or users are obliged to return old equipment produced by us free of cost. FunkTronic GmbH will dispose of this old equipment at its own expense according to regulations.

Please send old equipment for disposal to:

FunkTronic GmbH
Breitwiesenstraße 4
36381 Schlüchtern

>>> Important hint: freight forward deliveries cannot be accepted by us.

2 February, 2006

Subject to change, Errors excepted

Release Notes

- Oct-09, 2014 - Translation of German manual dated from Oct-08, 2014
- Nov-25, 2016 - Function C (simulate MOTOTRBO button) corrected